



## USER MANUAL – EN

### IN 23788 Pedometer inSPORTline Pacero



#### INTRODUCTION

This pedometer shows the number of steps and the distance traveled. Read the manual before using the device and keep it for future reference.

To maintain good health and reduce the risk of chronic health complications, it is recommended to take 10,000 steps a day. For effective weight loss, the total number of steps should be in the range of 12,000 to 15,000 steps. If you want to significantly improve your condition, it is recommended to take up to 30,000 steps a day.

#### DISPLAY

The display shows the number of steps and the distance traveled.

	
Number of steps	Distance traveled

#### USE

##### MODE button

Press to switch between modes.

Hold to reset the step and distance values (step mode only).

Hold to change units (only in step mode).

##### SET button

Press to set the step length.

Press to change the stride length (only in "distance" mode).

Press to change units (only in step mode).

#### SETTINGS

##### UNITS

Press the mode button to switch the pedometer to "step" mode.

Hold down the MODE button for 3 seconds to reset the number of steps and distance.

After resetting, keep the button pressed, the "units" will start flashing.

Press the SET button to toggle between mile / inch or km / cm.

Press MODE to confirm the change.

### **STEP LENGTH MEASUREMENT**

Measure the length of your stride.

- Mark a place on the ground. Take 10 steps, depending on what activity you are doing (running, jogging, walking, etc.)
- Mark the place where you took the last step.
- Divide the measured length by 10.

### **STEP LENGTH SETTING**

Press MODE in "distance" mode.

Press the SET button. The stride length value starts flashing.

When the value starts flashing, press the SET button to increase the value, hold down the button to increase the unit faster.

Press the MODE button to confirm the change.

### **BATTERY REPLACEMENT**

At the back, remove the screw holding the battery cover.

Remove the battery.

Insert a new battery, paying attention to the polarity of the battery.


Reattach the cover and secure the cover with the screw, do not overtighten the screw.

### **ATTACHING THE PEDOMETER**

Secure the pedometer with a clip to trousers or belt, ideally behind the hem.

Situations that can cause incorrect counting:

- The pedometer is not placed horizontally to the ground, the minimum angle to the ground must be 60°.
- Foot shuffling or uneven steps.
- Other than running or walking.
- Movement in the vehicle.
- Standing up, sitting, or walking up the stairs



### **MAINTENANCE AND SAFETY USE**

- Do not immerse in water, the product is not waterproof. Do not wash with water, do not handle with wet hands. Protect the device from water, the water must not enter the pedometer.
- For cleaning, use a soft cloth dampened with a solution of water and a mild detergent. Never use aggressive cleaning agents.
- Protect the product against impacts and falls.
- Store in a cool, dry place.
- Cold conditions can make the display harder to read, and readability should return to normal when the device warms to room temperature.
- Protect from direct sunlight, high temperatures, humidity, and dust.
- If you plan to store the device for a long time, remove the battery.

- Read the manual before use and keep it for future reference.
- Consult a doctor before starting demanding training program.
- Keep out of reach of children, the product contains small parts. There is a risk of suffocation.
- Read the manual carefully before use.
- Use only for the purpose for which the product was manufactured.
- Recycle the battery according to local ordinances and regulations.
- Do not dispose of the battery in a fire.

## **ENVIRONMENT PROTECTION**

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

## **TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS**

### **General Conditions of Warranty and Definition of Terms**

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### **Warranty Conditions**

#### **Warranty Period**

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

### **Batteries**

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

**The Warranty does not cover defects resulting from (if applicable):**

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

**Warranty Claim Procedure**

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**CZ  
SEVEN SPORT s.r.o.**

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR  
Headquarters: Dělnická 957, Vítkov, 749 01  
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264  
VAT ID: CZ26847264

Phone: +420 556 300 970  
E-mail: [eshop@insportline.cz](mailto:eshop@insportline.cz)  
[reklamace@insportline.cz](mailto:reklamace@insportline.cz)  
[servis@insportline.cz](mailto:servis@insportline.cz)

Web: [www.inSPORTline.cz](http://www.inSPORTline.cz)

**SK**  
**inSPORTline s.r.o.**

Headquaters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723

VAT ID: SK2020177082

Phone: +421(0)326 526 701

E-mail: [objednavky@insportline.sk](mailto:objednavky@insportline.sk)

[reklamacie@insportline.sk](mailto:reklamacie@insportline.sk)

[servis@insportline.sk](mailto:servis@insportline.sk)

Web: [www.inSPORTline.sk](http://www.inSPORTline.sk)